

## **Motoman Error 0380 POSITION NOT CHECKED**

**Cause:** When the Robot is powered off and transported, the Robot Arm tends to drift therefore causing the position values to differ from when the robot was powered down.

### **Remedy:**

1. Press the Robot menu icon on the left side of the screen on the Teach Pendant.
2. Select the Second Home Position menu icon on the screen by touching the icon.
3. In the bottom right hand corner of the Teach Pendant, Press the Modify button so the light turns ON.
4. Press the Enter button which is located beside the Modify button.
5. In the top left hand corner of the screen, select the Data menu icon by touching the icon.
6. A confirmation prompt should appear across the bottom of the screen.
7. The Robots home position has been reset, press the Cancel button to clear all errors.